

2.3.2. REAR BEARINGS ON THE CROSSMAX™ SL & SL DISC, CROSSMAX™ XL & XL DISC AND COSMIC CARBONE SL WHEELS

Tools needed:

- 1 x 5 mm Allen wrench
- 1 x 10 mm Allen wrench
- 1 hub wrench M40123
- Bearing pullers M40119

- 1 Disassemble the complete axle kit and the free wheel body kit following procedures 2.1.2. and 2.2.2.
- 2 Drive out the bearing on the free wheel side and then the bearing on the side opposite the free wheel using the bearing pullers M40119 (long shaft, see photo page 40).
- 3 After cleaning the body, mount the new bearings using the bearing pullers M40119.
- 4 Mount the free wheel body and axle kit following procedures 2.1.2. and 2.2.2.
- 5 Mount the wheel on the frame, tighten the quick release skewer, and adjust the bearing free play with the hub wrench M40123.

