

1.4. INSTALLATION OF THE PEDALING CADENCE OPTION

Tools needed

- 1 cutter

1. Insert a fixing tie in each of the pedaling cadence sensor slots provided for this purpose.
2. Place the sensor on the down tube or seat tube and close the fixing ties, without tightening them at first.
3. Remove the protection on the adhesive on the crank magnet and put it inside the crank, preferably on the pedal axle.
4. Adjust the position of the pedaling sensor so the crank magnet passes **facing one of the sensor indicators**.
5. Tighten the fixing ties and cut the ends off as short as possible.

