

REAR BEARING KIT FOR CROSSRIDE® AND COSMOS® WHEELS.

TOOLS NEEDED

- 1 x 5 mm Allen wrench.
- 1 x 16 mm wrench.
- 1 hub wrench M40123.
- Bearing pullers M40373.

- 1** Disassemble the axle kit (see page 12).
- 2** Remove the hub body bearings with the bearing pullers.
- 3** After cleaning the body, install the new bearing with the bearing tool.
- 4** Install the axle kit (see page 12).
- 5** Adjust the bearing free play (install the wheel to the frame and put the bike down on the floor) : the adjuster nut contacts the external side of the bearing with the hub wrench M40123.

Repeat this operation if the adjustment doesn't seem to be optimum.

