

1.1. DEEMAX 12x150 FREE WHEEL BODY AND PAWL ASSEMBLIES; DEEMAX 12x150 REAR AXLE

Tools needed

- 1 small flat screwdriver



Unclip the fork support nut on the free wheel side.



Pull the free wheel body into the hub axle.



Insert a small screwdriver under the pawl assembly at the right of the spring insertion hole and pull the spring to remove it from its housing.



Clean the free wheel body, grease the pawl assemblies and replace them in their housing. Insert the elbowed part of the spring into the insertion hole along the groove.



Delicately pull the right hand side of the spring and wind it around the pawl assemblies, ensuring it is correctly positioned at the bottom of the groove.



Re-insert the free wheel body into the hub body by pivoting it anti-clockwise.



Re-clip the fork support nut.