

## AUTOMATIC STARTING / ENERGY SAVING MODE



If after 10 minutes the computer has not received a signal, the main display is switched-off in order to conserve battery life. Only the clock remains displayed.

The computer comes back on automatically if it receives a signal or if either the L or R buttons are pressed.