

## AUTOMATIC SCANNING OF FUNCTIONS



When in the «Trip Distance» screen, press the L button to start the automatic scan.  
The functions will be scrolled through one after the other, each being displayed for **2** seconds.  
Press either the L or R button to return to normal mode.