

1.5. INSTALLATION OF THE COMPUTER, SENSOR SKEWER, PEDALING SENSOR, AND DERAILLEUR BATTERIES

Tools needed

- 1 coin
1. Remove the battery cover with a coin by turning it 1/4 turn counter clockwise.
 2. Check the condition of the seal on the battery cover. Replace it is damaged (reference 323 512 01).
 3. Put the battery in place in the computer, side + on the top.
 4. Put the battery cover back in place and close it by turning it 1/4 turn clockwise with a coin.



Always replace the battery in dry conditions.

Replacing the computer battery sets all the programs at zero :

- Cumulative odometer
- Unit of measurement (M or KM)
- Circumference of the wheel
- Time

Life of batteries : 12 - 24 months depending on the use.