

1.1.1. MOUNTING AND REMOVING THE CROSSMAX SL DISC LEFTY WHEEL ON THE CANNONDALE LEFTY FORK

Tools needed

- 1 x 5 mm Allen wrench

Mounting the wheel

The wheel can be mounted once the disc is screwed on to the hub.

1. Make sure there is a bearing seal on the disc side.
2. Insert the wheel on the projectile on the fork.
3. Tighten the wheel tightening screw with the 5 mm Allen wrench to a 15 Nm torque.



REMOVING THE WHEEL

Since the system used to tighten the wheel is self-extracting, you simply have to loosen the wheel tightening screw with the 5 mm Allen wrench until the wheel comes off.