

## REAR AXLE KIT FOR THE KSYRIUM® ELITE WHEEL

### Tools needed

- 2 x 5 mm Allen wrenches • 1 hub wrench M40123

- 1** Loosen the free play adjustment nut one turn using the hub wrench M40123, to avoid damaging the bearings when mounting the axle again;
- 2** Insert a 5 mm Allen wrench in each end of the axle;
- 3** Loosen the axle end screw using the 2x 5 mm Allen wrenches;
- 4** Remove the axle by pushing on the axle end screw to extract it on the opposite side of the free wheel;
- 5** Replace the axle and mount it again using the 2 x 5 mm Allen wrenches;
- 6** Mount the wheel on the frame (or the fork) and adjust the bearing free play using the hub wrench M40123.

