

3. INSTALLATION OF THE HOME-TRAINER OPTION

Tools needed

- None!
1. Install the wheel magnet bracket on a rear wheel spoke, on either the right or left side (see above procedure);
 2. Position the Home-Trainer sensor on the frame stand, facing downwards, at the same height as the wheel magnet bracket;
 3. Wrap the elastic string around the stand and then through the loop at the other side of the sensor;
 4. Pull strongly on the string and tighten the wedge so that the sensor is correctly adjusted on the frame;
 5. Adjust the position of the Home Trainer sensor such that the wheel magnet passes **in front of one of the marks** on the sensor.

