

AXLE KIT M40130 FOR THE IO® WHEEL.

TOOLS NEEDED :

- Two 5 mm Allen wrenches.
- One 14 mm flat wrench.
- Lock ring pliers.
- 1 vice with 1 set of clamps.



Disassemble the attachment nut M40124 beforehand with the 5 mm Allen wrenches.

Replacing the axle :

- 1** Remove the clips on the adjustment nut side with the pliers.
- 2** Loosen the adjustment nut with the 14 mm flat wrench holding the axle in a vice by using the clamps.
- 3** Remove the axle, clean the body if necessary, and replace it (installing in reverse order 1).
- 4** Adjust the bearing free play (install the wheel to the frame and put the bike down on the floor) : the adjuster nut contacts the external face of the bearing when using the 14 mm flat wrench. Repeat this operation if the adjustment doesn't seem to be optimum..

For adjusting the free play (see point 4 above).

