

REAR BEARING KIT CROSSMAX® UST®, KSYRIUM® SSC® AND COSMIC® CARBONE SSC®.

TOOLS NEEDED

- 2 x 5 mm Allen wrenches.
- 1 x 10 mm Allen wrench.
- 1 hub wrench M40123.
- Bearing pullers :
 - M40119 for Crossmax® UST® and Ksyrium® SSC® wheels.
 - M40120 for Cosmic® Carbone SSC® wheel.

1 Disassemble the complete axle kit and the free wheel body FTS kit (see pages 11, 12, 14, 15).

2 Remove the pawl assembly and the springs.

3 Remove the axle bearing on the free wheel side from the hub and then the axle bearing opposite the free wheel side with the bearing pullers.

4 After cleaning the hub body, replace the bearing kit with the bearing tools M40119 or M40120.

5 Install the free wheel FTS system (see pages 14 - 15).

6 Install the complete axle kit (see 11 - 12).

7 Adjust the bearing free play (install the wheel to the frame and put the bike down on the floor) : the adjuster nut contacts the external side of the bearing with the hub wrench M40123.

Repeat this operation if the adjustment doesn't seem to be optimum.

