

REAR AND FRONT AXLE KIT FOR CROSSMAX® UST® AND KSYRIUM® SSC® WHEELS.

TOOLS NEEDED

- 1 x 5 mm Allen wrench.
- 1 x 10 mm Allen wrench.
- 1 hub wrench M40123.

Replacing the axle :

- 1 Unclip the axle end screws (on the adjustment nut side).
- 2 Insert the 10 mm Allen wrench on the adjustment nut side and the 5 mm wrench on the opposite side.
- 3 Loosen the axle end screw.
- 4 Remove the axle and disassemble the adjustment nut if it is necessary.
- 5 Replace the axle and the adjustment nut if it is necessary.
- 6 Install the axle after loosening the adjustment nut one turn with the axle end screw, with the 5 and 10 mm Allen wrenches.
Torque : 6 - 8 N.m.
- 7 Clip the axle end screw
- 8 Adjust the bearing free play (install the wheel to the frame and put the bike down on the floor) : the adjuster nut contacts the external side of the bearing when using hub wrench M40123.
Repeat this operation if the adjustment doesn't seem to be optimum.

For adjusting the free play (see point 8 above).

